

TheLin Hearth Products

How To Replace the Switch Panel




Table of Contents

1.	How to replace the Switch Panel in the Parlour and Gnome Pellet Stove	3
----	--	---

How to Replace the Switch Panel in the Parlour & Gnome Pellet Stove

Step 1

CAUTION: Unplug power cord prior to performing any service on stove. Ensure stove has cooled down.

Locate Switch Panel on stove. When facing the front of the stove the Switch Panel is located on the right hand side.



Step 2

Remove (2) black 8-32 phillips pan head screws.



Step 3

Carefully lift Switch Panel out of Wrapper and unplug connector.

Reinstall in reverse order of removal.

